Miele

Operating instructions



Cooker hood
DA 6000 W

To avoid the risk of accidents or damage to the appliance it is **essential** to read these instructions before it is installed or used for the first time.

en - GB

M.-Nr. 09 204 950

Contents

Caring for the environment 4
Warning and Safety instructions 5
How the cooker hood works 11
Guide to the appliance 12
Miele@home 14
Con@ctivity 14
Operation 15
Hinged canopy 15
To switch the fan on ⏻ 15
To select a power level 15
Run-on option "5 15" 16
To switch the fan off ⏻ 17
To switch off the fan without closing the canopy 17
Hob lighting 17
Feature lighting 18
Operating hours counter 18
Sensor tones 20
For your safety 21
Safety switch-off for the canopy 21
Safety switch-off for the glass slats 21
Problem. 22
Safety switch-off after 10 hours 22
Cleaning and care 23
Housing 23
Position for maintenance 24
To open the housing 24
To close the housing. 25
Grease filters 25
Resetting the grease filter operating hours counter 26
Cleaning and care 27
Changing a lamp 27
After sales service 28

Contents

Installation 29
Installation diagram 29
Fixings 29
Appliance dimensions 30
Safety distance between hob and cooker hood (S) 31
Connection for air extraction 32
Condensate trap 33
Electrical connection 34
Operation with Control module DSM 400 35
Potential free connection 35
Connection to a light switch 35
Technical data 36

Caring for the environment

Disposal of the packing material

The transport and protective packing has been selected from materials which are environmentally friendly for disposal, and should be recycled.

Packaging e.g. cling film, polystyrene and plastic wrappings must be kept out of the reach of babies and young children. Danger of suffocation!

Disposal of your old appliance

Electrical and electronic appliances often contain materials which, if handled or disposed of incorrectly, could be potentially hazardous to human health and to the environment. They are, however, essential for the correct functioning of your appliance. Please do not therefore dispose of it with your household waste.



Please dispose of it at your local community waste collection / recycling centre or contact your dealer for advice. Ensure that it presents no danger to children while being stored for disposal.

This appliance complies with all relevant local and national safety requirements. Inappropriate use can, however, lead to personal injury and damage to property.

To avoid the risk of accidents and damage to the appliance, please read these instructions carefully before using it for the first time. They contain important information on safety, installation, use and maintenance.

Keep these instructions in a safe place and ensure that all users are familiar with the contents. Pass them on to any future owner of the appliance.

Correct application

▶ This appliance is intended for use in domestic households and in similar working and residential environments such as:

– Shops

– Offices and showrooms

and by residents in establishments such as:

– Hostels and guest houses.

▶ It must only be used as a domestic appliance to extract vapours and remove odours from cooking.

▶ The cooker hood is not intended for outdoor use.

Any other usage is not supported by the manufacturer and could be dangerous. Miele cannot be held liable for damage resulting from incorrect or improper use or operation.

▶ This appliance is not intended for use by people with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they are supervised whilst using it or have been shown how to use it correctly by a person responsible for their safety.

Safety with children

▶ This appliance is only intended for use by adults who have read these instructions.

▶ This appliance is not a toy! To prevent the risk of injury do not let children play with the appliance or its controls.

▶ Children under 8 years of age must be kept away from the cooker hood unless they are constantly supervised.

▶ Children 8 years and older may use the cooker hood only if they have been shown how to use it in a safe way and understand the hazards involved.

▶ Please be aware that on cooker hoods with halogen lighting, the lamps will get very hot during use and remain hot for some time after switching off. To safeguard against burning, keep children well away from the lamps at all times.

Technical safety

▶ Before installation, check the cooker hood for visible signs of damage. Under no circumstances should you install or use a damaged appliance. It could be dangerous.

▶ Before connecting the appliance to the mains supply, make sure that the connection details given on the data plate correspond with the on-site electricity supply; otherwise the appliance could get damaged. Consult a qualified electrician if in any doubt.

▶ The electrical safety of this appliance can only be guaranteed if correctly earthed. It is most important that this basic safety requirement is observed and tested regularly, and where there is any doubt, the household wiring system should be inspected by a qualified electrician. The manufacturer cannot be held liable for the consequences of an inadequate earthing system (e.g. electric shock).

▶ For safety reasons, this appliance may only be used when it has been fully installed.

▶ Only open the housing as described in the instructions given in the installation sheet and in the Cleaning and care section of this booklet. Under no circumstances should any other parts of the housing be opened. Tampering with electrical connections or components and mechanical parts is highly dangerous to the user, and can cause operational faults.

▶ Installation, maintenance and repairs may only be carried out by a Miele authorised person in strict accordance with current national and local safety regulations.
Repairs and other work by unqualified persons could be dangerous. The manufacturer cannot be held liable for unauthorised work.

▶ A damaged connection cable must only be replaced by an approved and suitably qualified technician.

▶ Faulty components must only be replaced by genuine Miele original parts. The manufacturer can only guarantee the safety of the appliance when Miele replacement parts are used.

▶ During installation, maintenance and repair work, the appliance must be disconnected from the mains electricity supply.

▶ Do not connect the appliance to the mains electricity supply by a multi-socket unit or an extension lead. These do not guarantee the required safety of the appliance (e.g. danger of overheating).

▶ This appliance must not be used in a non-stationary location (e.g. on a ship).

▶ In areas which may be subject to infestation by cockroaches or other vermin, pay particular attention to keeping the appliance and its surroundings in a clean condition at all times. Any damage which may be caused by cockroaches or other vermin will not be covered by the guarantee.

Using at the same time as other heating appliances that depend on the air from the room

⚠ Warning - danger of toxic fumes



▶ Great care should be taken when using the cooker hood at the same time and in the same room or area of the house as another heating appliance which depends on the air in the room. Such appliances include gas, oil, wood or coal-fired boilers and heaters, continuous flow or other water heaters, gas hobs, cookers or ovens which draw air in from the room and duct exhaust gases out through a chimney or extraction ducting.
When used in extraction mode, the appliance draws air in from the room in which it is installed **and** from neighbouring rooms.
If there is insufficient air, an underpressure will occur. The heating appliance may be starved of oxygen, impairing combustion.

Harmful gases could be drawn out of the chimney or extraction ducting back into the room, with potentially fatal consequences.

In order to ensure safe operation, and to prevent gases given off by the heating appliances from being drawn back into the room when the cooker hood and the heating appliance are in operation simultaneously, an underpressure in the room of 0.04 mbar (4 pa) is the maximum permissible.



Ventilation can be maintained by air inlets which cannot be blocked, in windows, doors and outside wall vents, or by other technical measures, such as ensuring that the cooker hood can only be switched on when the heating appliance is switched off or vice versa. A ventilation brick alone is not generally sufficient to ensure safe ventilation.

⚠ The overall ventilation condition of the dwelling must be taken into account. If in any doubt, the advice of a competent builder or, for gas, a qualified gas fitter (GasSafe registered in the UK) or electrician must be sought.

Correct use

▶ Always switch the cooker hood on when a cooking zone is in use, otherwise condensation may collect in the hood, which could cause corrosion.

▶ The cooker hood is operated by opening the hinged canopy. When opening or closing the canopy, do not place your hand inside the hood or between the glass slats.

▶ Do not use pots or pans that are taller than the lower edge of the cooker hood. Opening the canopy could dislodge the pot or pan, or the pot or pan could damage the cooker hood. This rule also applies to other items placed on the hob.

▶ When cooking with oil or fat, chip pans and deep fat fryers etc, do not leave the pans unattended. Never leave an open grill unattended when grilling. Overheated oil and fat can ignite and could set the cooker hood on fire.

▶ Do not use the cooker hood without the filters in place. This way you will avoid the risk of grease and dirt getting into the appliance and hindering its smooth operation.

▶ The filters should be regularly cleaned or changed as appropriate. Saturated filters are a fire hazard. See "Cleaning and care".

▶ The cooker hood can get very hot during cooking due to heat rising from the hob.
Do not touch the housing or the grease filters until the cooker hood has cooled down.

▶ Do not use a steam-cleaner to clean this appliance. Steam could reach the electrical components and cause a short circuit.

Correct installation

▶ Do not install this cooker hood over a gas hob.

▶ Check with the manufacturer of your cooking appliance whether it is safe to install a hood above it.

▶ The minimum safety distances between the top of the cooker or hob and the bottom of the cooker hood given in the "Appliance dimensions" section of this booklet must be maintained, unless the hob manufacturer states that a greater safety distance is required.

If more than one appliance is fitted beneath the cooker hood, and they have different minimum safety distances to the cooker hood, select the greater distance.

▶ Safety regulations prohibit the fitting of a cooker hood over solid fuel stoves.

▶ All ducting, pipework and fittings must be of non-flammable material. These can be obtained from the Miele Spare Parts department or from builders' merchants.

▶ The appliance must not be connected to a chimney or vent flue which is in use. Neither should it be connected to ducting which ventilates rooms with fireplaces.

▶ If exhaust air is to be extracted into a chimney or ventilation duct no longer used for other purposes, seek professional advice.

Accessories

▶ Only use genuine Miele original spare parts and accessories with this appliance. If spare parts or accessories from other manufacturers are used, this will invalidate the guarantee, and Miele cannot accept liability.

The manufacturer cannot be held liable for damage caused by non-compliance with these Warning and Safety instructions.

When the canopy is tilted forwards, cooking vapours are drawn into the open glass slats, through the grease filters inside the cooker hood and then conducted outside.

The re-usable metal grease filters remove solid particles (grease, dust, etc.) from the kitchen vapours, preventing soiling of the cooker hood.

The exhaust socket can be fitted with the **non-return flap** supplied. This flap is closed when the cooker hood is switched off. No exchange of room and outside air can take place.

When the cooker hood is switched on, the non-return flap opens for the cooking vapours to be blown directly outside.


A
1
2
B
3
4
C
5



Ⓐ Position when switched off

Ⓑ Position when switched on

Canopy and slats open

Ⓒ Position for maintenance

Position for cleaning inside the cooker hood, for removing the grease filters and for changing the lamp.

① Control panel

The symbols act as touch controls. Touch the sensors to select the function you require.
An audible tone sounds briefly to confirm selection.

② Feature lighting

The lowest glass slat is illuminated.

③ Canopy

The canopy tilts forward and the glass slats open as soon as the fan or the hob lighting is switched on.

④ Hob lighting

⑤ Grease filters

⑥ Sensor for the feature lighting

⑦ Sensor for hob lighting

This sensor switches the hob lighting on and off, and is also a dimmer switch.

⑧ Sensor for switching the fan on and off

⑨ Sensors to select the fan power level

⑩ Sensor for the run-on option

The fan can be set to switch off automatically after either 5 or 15 minutes.

⑪ Touch control for the grease filters

The touch control lights up when the grease filters need to be cleaned.

The touch control is used to reset the operating hours counter every time the grease filters are cleaned (see "Cleaning and care").

It can also be used to check and alter the operating hours counter.

For information about using the appliance, see "Operation".

Con@ctivity

This cooker hood is communication enabled.



Communication module XKM 2000 DA ①, available as an optional extra, enables the operation of the cooker hood to be automatically controlled by the operating status of a Miele electric hob with onset controls.

For communication to take place, the hob must be fitted with the relevant hob communication module ②.

The hob transmits information about its operating status to the cooker hood via the household power supply (Powerline) ③.

– When the hob is switched on, the canopy opens, the cooker hood hob lighting switches on and after a short time the cooker hood fan switches on.
– During cooking, the cooker hood automatically sets its power level according to the number of cooking zones in operation and their power levels.
– After switching the hob off, the cooker hood fan and hob lighting will switch off automatically after a period of time.
  The canopy remains open.

The communication module is fitted when the cooker hood is installed in the area of the motor and is connected to the controls of the cooker hood.
The appliance specific control cabling set is also required.

For detailed information about this function and fitting instructions, please read the operating instructions for the XKM 2000 DA and the installation instructions for the control cabling set.

Installation must be carried out by a Miele service technician or suitably qualified electrician.

Communication module
XKM 2000 DA . . . . . M.-Nr. 7 209 000

Control cabling set
DA 6000 W . . . . . M.-Nr. 7 707 980

Hinged canopy

The cooker hood is operated by opening the hinged canopy.
It opens by touching the On/Off sensor ⏻ or the Hob lighting sensor ☼.
It closes by touching the On/Off sensor ⏻.

⚠ When opening or closing the canopy, do not place your hand or catch your fingers inside the hood or between the glass slats.

To switch the fan on ⏻

■ Touch the On/Off sensor ⏻.



The canopy opens and three of the slats extend.
The fan then comes on at power level **2**.
The On/Off ⏻ and **2** sensors light up.

If the On/Off sensor ⏻ is touched whilst the canopy is opening, the canopy stops.
If the On/Off sensor ⏻ is touched again, the canopy shuts again.
Then the slats extend and close again.

To select a power level

Depending on the intensity of the cooking vapours, levels **1** to **3** are usually sufficient for normal cooking.

■ Select the level you require by touching the **1**, **2** or **3** sensors.

Intensive setting

■ For short periods of cooking food with intensive vapours and a strong aroma, e.g. when searing meat, you may wish to select level **4**, the Intensive setting.

Automatic switch-off of the Intensive setting

You can set the Intensive setting so that it always only runs for 10 minutes before reverting automatically to level **3**.

- To set this option, both the fan and the hob lighting must be switched off.

- Touch the Run-on sensor for approx. 10 seconds until the **1** sensor lights up.
- Touch in turn

– the Hob lighting sensor ☼,

– the **1** sensor, and

– the Hob lighting sensor ☼ again.

If Automatic switch-off is not activated, the **1** and **4** sensors will flash.

- Touch the **4** sensor to activate Automatic switch-off.
  The **1** and **4** sensors will now light up constantly.
  Touch the **1** sensor to deactivate the Automatic switch-off function.
- Touch the Run-on sensor sensor to confirm your selection.

If you do not confirm your selection within 4 minutes, the cooker hood will automatically revert to the original setting.

Run-on option "5 15"

It is advisable to leave the fan running for a few minutes after cooking has finished to neutralise any lingering odours in the air.

The fan can be set to switch off automatically after either 5 or 15 minutes.

- After cooking has finished, touch the Run-on option sensor whilst the fan is still running –

– Touch once = The fan will switch off after 5 minutes (**5** lights up).

– Touch twice = The fan will switch off after 15 minutes (**15** lights up).

The canopy will remain open.

- If you touch the Run-on sensor again, the fan remains on (**5 15** goes out).

To switch the fan off ⏻

- Touch the On/Off sensor ⏻ to switch the fan off.

The canopy and the slats will close.

If the On/Off sensor ⏻ is touched whilst the canopy is closing, the canopy will stop and the slats will stay open.
If the On/Off sensor ⏻ is touched again, the canopy will open again. The slats will shut and then open again.
The fan switches on again.

To switch off the fan without closing the canopy

The fan can also be switched off without closing the canopy (e.g. to be able to continue using the hob lighting).

- Whilst the fan is running, touch the sensor for the current fan setting for approx. 1 second until the fan switches off.
  The canopy will remain open.
- To switch the fan on again, touch one of the fan setting sensors.

Hob lighting ☼

The hob lighting can be switched on and off independently of the fan.

To switch the hob lighting on

- Touch the Hob lighting sensor ☼ briefly.

If the canopy is closed, it will now tilt forwards and the slats will open.

The hob lighting will then switch on at maximum brightness.

The Hob lighting sensor ☼ and the On/Off sensor ⏻ will light up.

To dim the hob lighting

The brightness of the hob lighting can be adjusted.

- With the hob lighting switched on, touch and hold the Hob lighting sensor ☼.
  The brightness will gradually dim until you release the sensor.
- To increase the brightness, touch the Hob lighting sensor ☼ again to the level required, then release it.

If you keep your finger on the Hob lighting sensor ☼, the lighting will continue to change between bright and dim.

To switch the hob lighting off

- Touch the Hob lighting sensor briefly. The canopy will remain open.
- The light will also switch off if the canopy is closed by touching the On/Off sensor ⏻.

Feature lighting

- When the canopy is closed, the lower glass slat can be illuminated by touching the Feature lighting sensor.

When the canopy is opened, the Feature lighting will switch off.

Operating hours counter

The number of hours the appliance has been in operation is stored in memory.

The operating hours counter tells you when the grease filters need to be cleaned.

After 30 hours of operation (or another time if the operating hours counter has been altered), the Grease filter sensor will light up.

The grease filters must then be cleaned and the operating hours counter reset (see "Cleaning and Care").

Reading the grease filter operating hours counter

To check the percentage of time set already used

- Press the On/Off sensor ⏻ to switch the fan on.
  Wait until the canopy has opened and the fan is running.
- Touch and keep your finger on the Grease filter sensor.

One or more of the **1** to **4** sensors will flash.

The number of flashing sensors indicates the percentage of the operating time which has already been used up.

Sensor **1**	=	25 %
Sensors **1** and **2**	=	50 %
Sensors **1** to **3**	=	75 %
Sensors **1** to **4**	=	100 %

- When you take your finger off the Grease filter sensor, the current fan setting will show.

The number of operating hours used remains in the memory, even when the appliance is switched off or there is a power cut.

Altering the grease filter operating hours counter

You can set the operating hours counter to suit the type of cooking you do.

The operating hours counter is set at the factory for 30 hours.

Select a shorter time of 20 hours if you fry a lot.

If you only cook occasionally, we still recommend 20 hours because grease which has built up gradually over a long period of time will harden on the grease filters and make cleaning more difficult.

If you use very little fat for cooking, select a longer time of 40 or 50 hours.

To alter the operating time:

- Press the On/Off sensor ⏻ to switch the fan off.
  Wait until the canopy is closed and the On/Off sensor ⏻ has gone out.
- Touch the Run-on sensor and the Grease filter sensor at the same time.

The Grease filter sensor and one of the fan power level sensors **1** to **4** will flash.

The **1** to **4** sensors indicate the time set:
1 = 20 hours
2 = 30 hours
3 = 40 hours
4 = 50 hours

- Touch the **1** sensor to select a shorter time and the **4** sensor to select a longer time, until the time required has been set.
- Touch the Grease filter sensor ⊛ to confirm your selection.

All the lamps will go out.

If you do not confirm your selection within 4 minutes, the cooker hood will automatically revert to the original setting.

Sensor tones

When selecting a function with the sensors, an audible tone will sound briefly to confirm.

The audible tone can be deactivated.

- Switch the fan off by touching the On/Off sensor ⏻.
  Wait until the canopy has closed and the On/Off sensor ⏻ has gone out.
- Touch the **4** sensor and the Grease filter sensor ⊛ at the same time for approx. 5 seconds until a tone sounds briefly. The audible tone is now switched off for all functions.
- To reactivate the audible tone, repeat the above process.

After the cooker hood has been disconnected from the mains electricity supply or after a power cut, the audible tone is activated regardless of the last setting.

For your safety

Safety switch-off for the canopy



If the canopy is prevented from closing by someone's hand or an object blocking it, it will be released from the upper locking mechanism, spring open and stop closing.

A long audible tone will sound four times.

The canopy is now in the "maintenance" position (see "Cleaning and care").

- Once the obstruction has been removed, the canopy housing must be closed up again (see "Cleaning and care - To close the housing").
- Then switch the cooker hood on again by touching the On/Off sensor ⏻. Wait until the glass slats have reopened correctly.
- Finally, switch the cooker hood off again by touching the On/Off sensor ⏻.
  The canopy and the slats will close.

Safety switch-off for the glass slats

The glass slats are spring loaded. They yield if they are blocked by somone's fingers or another object.



The extendable slats also have a release mechanism. If there is a blockage, they might get stuck in the open or shut position.

- Remove the cause of the blockage.

The glass slats will automatically correct themselves when the canopy is opened and shut.

- To do this, switch the cooker hood on again by touching the On/Off sensor ⏻. Wait until the canopy has opened and the fan is running.
- Then switch the cooker hood off again by touching the On/Off sensor ⏻.

The canopy will close.

If the glass slats have not corrected themselves, switch the cooker hood on and then off again.

Problem

If the canopy stops whilst it is being opened or closed and you hear a long tone sounding 4 times, this means that the canopy's safety switch-off has been activated.

- Make sure that the neither the canopy nor the glass slats have been blocked by anything.
- Then close the canopy housing up again (see "Cleaning and care - To close the housing").
- Switch the cooker hood on again by touching the On/Off sensor ⏻. Wait until the glass slats have reopened correctly.
- Finally, switch the cooker hood off again by touching the On/Off sensor ⏻.

If the canopy stops whilst it is being opened or closed, and the Run-on sensor is flashing, there is a fault.

- If this happens, touch the On/Off sensor ⏻.

The canopy will move in the opposite direction.

If the fault occurs again, please contact the Service department (see "After Sales Service").

Safety switch-off after 10 hours

Should the cooker hood be left on, the fan will switch off automatically after 10 hours.
The hob lighting will remain on. The canopy will remain open.

- The fan can be switched on again by touching the power level sensor **1** to **4** required.

A range of Miele branded cleaning and care products are available to order via the internet on www.miele-shop.com.

⚠ Halogen lamps get very hot during use and remain hot for some time after being switched off. The hot lamps are also susceptible to damage from damp cleaning. Wait a few minutes after switching off before commencing cleaning.

Housing

General

The surfaces are susceptible to scratches and abrasions. Please observe the following cleaning instructions.

- All external surfaces and controls can be cleaned using a Miele E-Cloth or with warm water and a little washing-up liquid applied with a well wrung-out soft sponge or cloth.

Only use a damp cloth as water could get into the appliance and cause damage.

- Wipe the surfaces dry using a soft cloth.

Do not use:

– cleaning agents containing soda, acids, chlorides or solvents,

– abrasive cleaning agents, e.g. powder cleaners or cream cleaners, and abrasive sponges, e.g. pot scourers or sponges which have been previously used with abrasive cleaning agents. These will damage the surface material.

Important for appliances with stainless steel surfaces

- Stainless steel surfaces can be cleaned using the Miele E-Cloth or with a suitable, non-abrasive, proprietary cleaning agent for stainless steel, following the manufacturer's instructions on the packaging.
- To help prevent re-soiling, a proprietary conditioning agent for stainless steel can also be used. Follow the manufacturer's instructions on the packaging.

Important for appliances with glass surfaces

- Glass surfaces can be cleaned using a proprietary non-abrasive cleaning agent designed specifically for use on glass.

Do not use:

– sharp metal tools,

– oven sprays.

Position for maintenance



The housing can be opened to clean inside the cooker hood, remove the grease filters and to change the lamps.

To open the housing

- Switch the cooker hood on by touching the On/Off sensor ⏻ or the Hob lighting sensor ☼. The canopy will open into the operating position.
- Before opening the housing, clear everything from the hob.
- Holding the canopy on both sides of the frame ①, pull it down into a horizontal position as shown (you will feel a resistance).

Only pull on the outside edge of the frame ①.
Do not pull on the filter housing ② or on the glass slats ③.

The canopy ① hinges downwards whilst the filter housing ② hinges upwards.

The fan and the hob lighting switch off and cannot be switched on again whilst the cooker hood is in the maintenance position.

The open canopy cannot bear any weight.
Do not lean on the open canopy or place any objects on it.

To close the housing



- To close the housing again, raise the canopy ① up by pushing on the second glass slat from the top as shown, until it engages back into the filter housing ②.

Do not push on the extended glass slats.

Make sure that the canopy is correctly engaged on the left and right hand side, otherwise the cooker hood cannot be switched on again.

- The fan can be switched on again by touching the power level sensor **1** to **4** required.
- The hob lighting can be switched on again by touching the Hob lighting sensor ☼.

Grease filters

The grease filters should be cleaned regularly (at least every 3-4 weeks) to avoid a build-up of grease.

They should be cleaned immediately if the ▨ sensor lights up.

⚠ An oversaturated filter is a fire hazard.

- To remove the grease filters, lower the cooker hood into the maintenance position (see "Position for maintenance").



- Open the catch for the grease filters, hinge the filter forwards as shown, and lift out.

Cleaning the grease filters by hand

- Clean the filters with a soft nylon brush in a mild solution of hot water and a little washing-up liquid.
  Do not use "neat" washing up liquid.

Do not use:

– cleaning agents containing descaling agents,

– powder cleaners, cream cleaners or abrasive all-purpose cleaners.

– oven sprays.

Cleaning the grease filters in the dishwasher

- Place the filters as upright as possible in the lower basket, with the short sides upright. Make sure that the spray arm can move freely.
- Do not wash at more than 65° C. If a Miele dishwasher is being used, select the Sensor wash programme.
- Use a mild dishwasher detergent.

Depending on the cleaning agent used, cleaning the filters in a dishwasher can cause permanent discolouration to the surface. However, this will not affect the functioning of the filters in any way.

- After cleaning, leave the filters to dry on an absorbent surface before replacing them.



- Whilst the grease filters are removed, to prevent the risk of fire, clean grease deposits from the accessible parts of the housing and the channel in the lower part of the housing.
- Replace the grease filters.
- Close the canopy (see "To close the housing").
- The fan can be switched on again by touching the power level sensor **1** to **4** required.

Resetting the grease filter operating hours counter

After cleaning, the operating hours counter needs to be reset.

- Whilst the fan is switched on, touch the Grease filter sensor ⊛ for approx. 3 seconds until only the **1** is flashing.
  The Grease filter sensor ⊛ will go out.

If you want to clean the grease filters **before** the operating hours counter has reached its maximum,

- Touch the Grease filter sensor ⊛ for approx. 6 seconds until only the **1** is flashing.

Changing a lamp

⚠ Exercise caution when changing halogen lamps. They get very hot during use, and remain hot for some time after being switched off: danger of burning.
Wait until the lamps have cooled down before changing them.

- To change a halogen lamp, lower the canopy into the maintenance position; see "Position for maintenance".
- Before any cleaning or maintenance work, disconnect the cooker hood from the mains supply (See "Warning and Safety Instructions").



- Loosen the screws for the cover behind the top glass slat.
- Remove the cover.
- Pull the halogen lamp out of its socket.



- Use a cloth or glove to fit the new halogen lamp into its socket and carefully push it into position.

Halogen lamps required: 20 W with G 4 connector and side reflector, (can be purchased from Miele).

It is important that the halogen lamps have a side reflector.
Fit the lamps so that the light is directed through the gap between the first and second glass slats.

- Refit the lamp cover using the two screws.
- Close the canopy again; see "Position for maintenance".
- Then reconnect the cooker hood to the mains electricity supply.

After sales service

In the event of a fault which you cannot correct yourself, or if the appliance is under guarantee, please contact:

– your Miele Dealer

or

– the Miele Customer Contact Centre (see back cover for address).

Please note that telephone calls may be monitored and recorded to improve our service.

When contacting Miele, please quote the model and serial number of your appliance. both of which are given on the data plate.

Position of the data plate



The data plate is located behind the grease filters. To remove the grease filters, the canopy must be lowered into the maintenance position (see "Cleaning and care").

Guarantee

For information on the appliance guarantee specific to your country please contact Miele. See back cover for contact details.

In the U.K. your appliance is guaranteed for 2 years from the date of purchase. To activate your cover call 0845 365 6640 or register online at www.miele.co.uk

Before installation it is important to read the information given on the following pages as well as the "Warning and safety" instructions at the beginning of this book.

Installation diagram

See enclosed Installation diagram for instructions on how to install this appliance.

Fixings

The screws and wall plugs which are supplied with the building-in frame DER 6000 are suitable for masonry walls.
For other types of wall, use appropriate fixings.

⚠ Make absolutely sure the wall is strong enough to bear the weight of the cooker hood.

Appliance dimensions



Safety distance between hob and cooker hood (S)

The safety distance between the top of a cooker or hob and the bottom of the cooker hood canopy must measure **at least 350 mm**, unless a greater distance is specified by the manufacturer of your cooking appliance.
See "Warning and Safety instructions".

Do not install this cooker hood over a gas hob.

– Account should also be taken of the height of the person who will be using the hood most often. The person should have sufficient space to work comfortably at the hob, and also be able to reach the hood controls with ease.
– Please be aware that if positioned too high, extraction will be inefficient.
– These building-in dimensions apply to hoods installed with building-in frame DER 6000.
– The position of the canopy in the building-in frame can be set forwards by up to 20 mm so that it can be aligned to a glass splashback, for example (detail C).

Connection for air extraction

⚠ Important: To avoid the danger of toxic fumes, please observe the Warning and Safety instructions. This is especially crucial when using the cooker hood at the same time as another heating appliance which relies on air from the same room. The cooker hood should be installed according to local and national building regulations. Seek approval from the building inspector where necessary.

– All ducting, pipework and fittings must be of non-flammable materials.
– The exhaust ducting should be as short and straight as possible.
– To ensure efficient air extraction, the diameter of the exhaust ducting should not be less than 150 mm.

If exhaust ducting with a diameter of less than 150 mm, or if flat ducting is used, the noise level of the cooker hood will increase and extraction will be less efficient.

Only reduce the diameter of the ducting if absolutely necessary, e.g. where narrower ducting has already been installed.

– Only use wide radius bends. Tight bends reduce the air throughput of the cooker hood.
– Only use smooth pipes or flexible hoses made from non-flammable materials for extraction connection.

If the exhaust ducting is secured to the exhaust stub by a hose clip, ensure that it is fitted correctly. Do not overtighten.
Otherwise the exhaust stub could buckle and the non-return flap could become jammed.

– Where ducting is horizontal, it must be laid to slope away at at least 1 cm per metre.

  This is to ensure that condensate cannot drain back into the cooker hood.

– If the exhaust air is to be ducted into the open air, the installation of a telescopic wall vent is recommended.



– If the exhaust air is to be ducted into a vent flue, the ducting must be directed in the flow direction of the flue.

Important:

If the exhaust ducting is to run through rooms, ceiling space etc. where there may be great variations in temperature between the different areas, the problem of condensation will need to be addressed. The exhaust ducting will need to be suitably insulated.

Condensate trap

(optional extra)



In addition to insulating the exhaust ducting, we recommend that a suitable condensate trap is also installed to collect and evaporate any condensate which may occur. Condensate traps are available for ∅ 125 mm or ∅ 150 mm ducting.

When installing a condensate trap, ensure that it is positioned vertically and if possible directly above the exhaust connection. The arrow on the housing indicates the direction of air-flow.

Electrical connection

All electrical work should be undertaken by a suitably qualified and competent person in strict accordance with current national and local safety regulations (BS 7671 in the UK).

Installation, repairs and other work by unqualified persons could be dangerous, for which the manufacturer cannot be held liable.

Ensure power is not supplied to the appliance until after installation or repair work has been carried out.

Do not connect the appliance to the mains electricity supply by an extension lead. These do not guarantee the required safety of the appliance.

The connection data is given on the data plate. This is visible when the grease filters have been removed. Ensure that this data matches the household mains supply.

Connection of this appliance should be made via a suitable isolator or a double pole fused spur connection unit which complies with national and local safety regulations and the On-Off switch should be easily accessible after the appliance has been built in.
When switched off there must be an all-pole contact gap of 3 mm in the switch (including switch, fuses and relays according to EN 60335).

If the switch is not accessible after installation (depending on country), an additional means of disconnection must be provided for all poles.

For extra safety it is advisable to protect the appliance with a suitable residual current device (RCD). Contact a qualified electrician for advice.

Important

This appliance is supplied for connection to an a.c. 230 V single phase 50 Hz supply.

The wires in the mains lead are coloured in accordance with the following code:

Green/yellow	= earth
Blue	= neutral
Brown	= live

WARNING:
THIS APPLIANCE MUST BE EARTHED

The Miele DSM 400 control module can be used to combine the cooker hood with other components.

It enables the following:

Potential free connection

This can be used to operate a further appliance via the On/Off button ⏻ on the cooker hood.

If in any doubt, the advice of a competent builder or, for gas, a Gas Safe installer must be sought.

Connection to a light switch

The control module can be used to switch on the hob lighting on the cooker hood and also to dim it, depending on model, via a light switch in the house.

If the hob lighting is activated by an external lightswitch, the canopy tilts forwards and the hob lighting is switched on.

If the hob lighting is switched off, the canopy remains open.

The feature lighting cannot be operated via the control module.

Installation

The control module is fitted to the cooker hood in the area of the fan and is connected to the controls on the cooker hood.

The electrical connection of components to the control module must be carried out by a suitably qualified and competent person.

Technical data

Total connected load. . . . . 504 W
– Fan motor . . . . . 290 W
– Canopy mechanism . . . . . 120 + 4 W
– Hob lighting . . . . . 4 x 20 W
– Feature lighting . . . . . 1 x 10 W

Voltage . . . . . AC 230 V

Frequency . . . . . 50 Hz

Fuse rating . . . . . 5 A

Weight. . . . . 54 kg

Fan performance according to EN 61591

Extraction power with ∅ 150 mm ducting:

Level I . . . . . 350 m^3/h
Level II. . . . . 500 m^3/h
Level III . . . . . 650 m^3/h
Level IV Intensive Setting . . . . 850 m^3/h

United Kingdom
Miele Co. Ltd.
Fairacres, Marcham Road
Abingdon, Oxon, OX14 1TW
Tel: 0845 365 0555
Fax: 0845 365 0777
Customer Contact Centre Tel: 0845 365 6600
E-mail: info@miele.co.uk
Internet: www.miele.co.uk

Australia
Miele Australia Pty. Ltd.
ABN 96 005 635 398
1 Gilbert Park Drive, Knoxfield, VIC 3180
Tel: (03) 9764 7130, Fax: (03) 9764 7149
Internet: www.miele.com.au

China
Miele (Shanghai) Trading Ltd.
1-3 Floor, No. 82 Shi Men Yi Road
Jing' an District
200040 Shanghai, PRC
Tel: +86 21 6157 3500
Fax: +86 21 6157 3511
E-mail: mieleshanghai@cn.miele.com
Internet: www.miele.cn

Miele (Hong Kong) Limited
41/F - 4101, Manhattan Place
23 Wang Tai Road
Kowloon Bay
Hong Kong
Tel: (852) 2610 1331
Fax: (852) 2610 1013
Email: mielehk@miele.com.hk

India
Miele India Pvt. Ltd.
Ground Floor, Copia Corporate Suites
Plot No. 9, Jasola
New Delhi – 110025
Tel: 011-46 900 000, Fax: 011-46 900 001
E-mail: customercare@miele.in
Internet: www.miele.in

Manufacturer: Germany - Miele & Cie. KG
Carl-Miele-Straße 29, 33332 Gütersloh

Ireland
Miele Ireland Ltd.
2024 Bianconi Avenue
Citywest Business Campus, Dublin 24
Tel: (01) 461 07 10, Fax: (01) 461 07 97
E-Mail: info@miele.ie, Internet: www.miele.ie

New Zealand
Miele New Zealand Limited
Unit L, 10-20 Sylvia Park Road
Mt. Wellington, 1060, Auckland, NZ
Tel: 0800 264 353, Fax: 0800 463 453
Internet: www.miele.co.nz

Singapore
Miele Southeast Asia
Miele Pte. Ltd.
163 Penang Road
04 - 02/03 Winsland House II
Singapore 238463
Tel: +65 6735 1191, Fax: +65 6735 1161
E-Mail: infosea@miele.com.sg
Internet: www.miele.sg

South Africa
Miele (Pty) Ltd
63 Peter Place, Bryanston 2194
P.O. Box 69434, Bryanston 2021
Tel: +27 (0) 11 548-1900
Fax: +27 (0) 11 548-1935
E-mail: info@miele.co.za
Internet: www.miele.co.za

United Arab Emirates
Miele Appliances Ltd.
P.O. Box 11 47 82
Gold & Diamond Park
Sheikh Zayed Road
Building 6 / Offices Nos. 6-214 to 6-220
Dubai
Tel: +971-4-341 84 44
Fax: +971-4-341 88 52
E-Mail: info@miele.ae
Internet: www.miele.ae

Alteration rights reserved / 3011

M.-Nr. 09 204 950 / 00

CE